

Mounting Sereno™ Panel

Sereno™ Panel can be mounted directly to walls and ceilings using adhesives or mechanical fasteners. In certain applications, it may be necessary to hang the panels, therefore we suggest using mechanical fasteners in conjunction with hanging hardware to achieve desired results.

TIP!

- Please ensure hands are clean prior to handling Sereno Panel

ADHESIVE SOLUTIONS

Sereno™ Panel can be adhered to surfaces directly using a non-solvent construction grade glue and certain types of construction grade double-sided tape. In certain applications, specifically ceiling installation, it is recommended that an adhesive be used in conjunction with mechanical fasteners to ensure the strongest possible hold.

SUGGESTED ADHESIVES

- Liquid Nails LN903
- Construction Grade Double-Sided Tape (e.g. Uline S7825)

MECHANICAL FASTENING

Sereno™ Panel can be fastened directly to surfaces using screws, nails, staples or z-clips. Using mechanical fasteners allows for panels to be easily installed and removed without too much damage to the panels themselves or the substrate.

TIPS!

- Drill holes inset from corner of Sereno™ Panel
- Avoid over tightening to prevent material from compressing
- Test mounting method before permanently fastening to substrate
- Use appropriate hardware for substrate

SPECIALIZED MOUNTING

In circumstances where acoustic performance is paramount it may be advantageous to create an air-gap behind the Sereno™ Panel. This can be done a number of ways, namely using furring strips or battens that have been fastened to the substrate before panel installation occurs.

**Other permanent & temporary solutions are available - please enquire for details.*

Cutting Sereno™ Panel

Sereno™ Panel can be cut with a heavy duty utility knife or a variety of tools typically used in woodworking (jigsaw, hand saw, table saw, band saw etc.). We suggest performing a test cut before making finished cuts.

Avoid overheating power tools as Sereno™ Panel material as overheating may cause material to fray or melt.

Sereno™ Panel Maintenance

Sereno™ Panel requires little maintenance. Simply vacuum with wand to remove surface dust or use a mild, non-toxic soap with warm water to wipe blots. Avoid saturating material.

Warranty

Sereno™ Panel is covered by a 1-Year Manufacture Warranty against all defects.